


APPENDIX A: PLANS FOR CONSTRUCTING COMPOST BINS

WOODEN-PALLET HOLDING UNIT

A holding unit can be built inexpensively using wooden pallets, or pressure-treated lumber may be used to make a nicer looking bin. The costs will vary, depending on whether new lumber or pallets are used. Used pallets are often available from manufacturers and landfills.



Building a Holding Unit Using Wooden Pallets

1. Nail or wire four pallets together to make a four-sided bin at least 3 feet x 3 feet x 3 feet. The bin is then ready to use.
2. A fifth pallet can be used as a base, to allow more air to get into the pile and to increase the stability of the bin.

Building a Holding Unit Using Lumber

1. Saw the 8-foot lengths of 2 x 4 pressure-treated lumber into four pieces, each 4 feet long, to be used as corner posts.
2. Choose a 3-foot-square site for your compost bin. Use the sledge hammer to pound the four posts into the ground 3 feet apart, at the corners of the square.
3. Saw each of the five 12-foot boards into four 3-foot pieces. Allowing five boards to a side and, starting at the bottom, nail the boards to the posts to make a four-sided container. Leave 2 inches between the boards to allow air to get into the pile.
4. If you wish to decrease your composting time, build a second holding unit so that the wastes in one can mature while you add wastes to the other.

Materials

- four wooden pallets (Five pallets if you want a bottom in the container), sized to make a four-sided container at least 3 feet x 3 feet x 3 feet
- nails
- baling wire
- or
- two eight-foot lengths of 2 x 4 pressure-treated lumber
- five 12-foot lengths of 1 x 6 pressure-treated lumber
- galvanized 8d nails (1 pound)

Tools

- saw
- sledge hammer
- claw hammer
- work gloves

WIRE-MESH HOLDING UNIT

A wire-mesh holding unit is inexpensive and easy to build out of either galvanized chicken wire or hardware cloth. (Nongalvanized chicken wire can also be used, but will not last very long.) Posts provide more stability for a chicken wire bin, but make the bin difficult to move. A wire-mesh bin made without posts is easy to lift, and provides access to the compost that is already "done" at the bottom of the pile while the compost at the top of the pile is still decomposing.

Materials


- at least a 10-foot length of 36-inch-wide 1-inch galvanized chicken wire
- or
- at least a 10-foot length of 1/2-inch-wide hardware cloth
(Note: The maximum bin diameter for a given length of chicken wire is the length of chicken wire divided by 3.14.)
- heavy wire for ties
- three or four 4-foot-tall wooden or metal posts (for chicken wire bin.)

Optional material for lid

- at least a 3-foot additional length of 36-inch-wide, 1/2-inch hardware cloth

Tools

- heavy-duty wire or tin snips
- pliers
- hammer (for chicken wire bin)
- metal file (for hardware cloth bin)
- work gloves



Building a Wire-Mesh Holding Unit Using Chicken Wire


1. Fold back 3 to 4 inches of wire at each end of the cut piece to provide a strong, clean edge that will not poke or snag, and that will be easy to latch.
2. Stand the wire in a circle and set it in place for the compost pile.
3. Cut the heavy wire into lengths for ties. Attach the ends of the chicken wire together with the wire ties, using pliers.
4. Space wood or metal posts around the inside of the chicken-wire circle. Holding the posts tightly against the wire, pound them firmly into the ground to provide support.

Building a Wire-Mesh Holding Unit Using Hardware Cloth

1. Trim the ends of the hardware cloth so that the wires are flush with a cross wire to get rid of edges that could poke or scratch hands. Lightly file each wire along the cut edge to ensure safe handling when opening and closing the bin.
2. Bend the hardware cloth into a circle, and stand it in place for the compost pile.
3. Cut the heavy wire into lengths for ties. Attach the ends of the hardware cloth together with the wire ties, using pliers.

SNOW-FENCE HOLDING UNIT

A snow-fence holding unit is simple to make. It works best with four posts pounded into the ground for support.



Building a Snow-Fence Holding Unit

1. Choose a 3-foot-square site for your holding unit, and pound the four wooden or metal posts into the ground 3 feet apart, at the corners of the square.
2. Cut the heavy wire into lengths for ties. Attach the snow fence to the outside of the posts with the wire ties, using pliers.
3. Attach the ends of the snow fence together in the same way, forming a 3-foot-square enclosure.

Materials

- four wooden or metal posts, 4-5 feet long (Use pressure-treated lumber for the wooden posts.)
- heavy wire for ties
- a 13-foot length of snow fencing, at least 3 feet tall (a 16-foot length with optional top)

Tools


- heavy-duty wire or tin snips
- pliers
- sledge hammer
- work gloves

CONCRETE-BLOCK HOLDING UNIT

A concrete-block holding unit is sturdy, durable, and easily accessible. If the concrete blocks must be purchased, a concrete-block holding unit may be slightly more expensive to build than the wire-mesh or snow-fence holding units. The concrete-block unit cannot be conveniently pest-proofed.

Materials and Tools

- about forty-six concrete blocks for the first bin
- (optional) about thirty-two blocks for a second bin
- wooden or metal posts to stabilize the bin
- work gloves




Building a Concrete-Block Holding Unit

1. Place five concrete blocks in a row along the ground at the composting site, leaving about 1/2 inch between each block to let in air.
2. Place four concrete blocks in another row along the ground perpendicular to, and at one end of, the first row, forming a square corner; leave about 1/2 inch between each block.
3. In the same way, place four concrete blocks at the opposite end of the first row to form a three-sided enclosure.
4. Add a second layer of blocks, staggering them to increase stability and leaving about 1/2 inch between each block. There should be a layer of four concrete blocks on each of the three walls of the enclosure.
5. Add a third layer of blocks, again staggering them to increase stability, with five blocks across the back of the enclosure and three on each side.
6. The last, and top, layer should have four blocks across the back and three on each side.
7. To make the bin more stable, drive wooden or metal posts through the holes in the blocks.
8. (Optional) If you wish to decrease your composting time, build a second bin next to the first, so that the wastes in one can mature while you add wastes to the other. Use one side wall of the first bin so that you only need to build two additional walls.


WOOD-AND-WIRE THREE-BIN TURNING UNIT

A wood-and-wire three-bin turning unit can be used to compost large amounts of yard, garden, and kitchen wastes in a short time. Although relatively expensive to build, it is sturdy, attractive, and should last a long time. Construction requires basic carpentry skills and tools. With optional lids and bottom, this unit can be made rodent-resistant.



Building a Wood-and-Wire Three-Bin System

1. Cut two 31 1/2-inch and two 36-inch pieces from a 12-foot length of pressure-treated 2 x 4 lumber. Butt-joint and nail the four pieces into a 35-inch x 36-inch "square." Repeat, building three more frames with the remaining 12-foot lengths of 2 x 4 lumber.



2. Cut four 37-inch lengths of hardware cloth. Fold back the edges of the wire 1 inch. Stretch the pieces of hardware cloth across each frame. Make sure the corners of each frame are square and then staple the screen tightly into place every 4 inches around the edge. The wood-and-wire frames will be dividers in your composter.
3. Set two dividers on end, 9 feet apart and parallel to one another. Position the other two dividers so that they are parallel to and evenly spaced between the end dividers. Place the 36-inch edges on the ground. Measure the position of the centers of the two inside dividers along each 9-foot edge.

Materials

- four 12-foot lengths of pressure-treated 2 x 4 lumber
- two 10-foot lengths of pressure-treated 2 x 4 lumber
- one 10-foot length of construction-grade 2 x 4 lumber
- one 16-foot length of 2 x 6 lumber
- six 8-foot lengths of 1 x 6 lumber
- a 22-foot length of 36-inch-wide 1/2-inch hardware cloth
- 16d galvanized nails (2 pounds)
- poultry wire staples (250)
- twelve 1/2-inch carriage bolts, 4 inches long, with washers and nuts
- one quart wood preservative or stain


Optional materials—for lids and bottom

- one 4-x-8-foot sheet of 1/2-inch exterior plywood
- one 4-x-4-foot sheet of 1/2-inch exterior plywood
- six 3-inch zinc-plated hinges
- twenty-four 3/16-inch galvanized steel bolts, with washers and nuts
- sufficient galvanized sheet metal to cover bottom of bins

Tools


- tape measure
- hand saw or circular power saw
- hammer
- tin snips
- carpenter's square
- drill with 3/16-inch and 1/2-inch bits
- screwdriver
- adjustable wrench
- pencil
- safety glasses, ear protection, dust mask, and work gloves

4. Cut a 9-foot piece from each 10-foot length of pressure-treated 2 x 4 lumber. Place the two treated boards across the tops of the dividers so that each is flush against the outer edges. Measure and mark on the 9-foot boards the center of each inside divider.
5. Line up the marks, and through each junction of board and divider, drill a 1/2-inch hole centered 1 inch from the edge. Secure the boards with carriage bolts, but do not tighten them yet. Turn the unit so that the treated boards are on the bottom.
6. Cut one 9-foot piece from the 10-foot length of construction-grade 2 x 4 lumber. Attach the board to the back of the top by repeating the process used to attach the base boards. Using the carpenter's square, or measuring between opposing corners, make sure the bin is square. Tighten all the bolts securely.
7. Fasten a 9-foot length of hardware cloth to the back side of the bin, with staples every 4 inches around the frame.
8. Cut four 36-inch-long pieces from the 16-foot length of 2 x 6 lumber for front runners. (Save the remaining 4-foot length.) Rip-cut two of these boards to two 4 3/4-inch-wide strips. (Save the two remaining strips.)
9. Nail the 4 3/4-inch-wide strips to the front of the outside dividers and baseboard so that they are flush on the top and the outside edges. Center the two remaining 6-inch-wide boards on the front of the inside dividers flush with the top edge and nail securely.
10. Cut the remaining 4-foot length of 2 x 6 lumber into a 34-inch-long piece, and then rip-cut this piece into four equal strips. Trim the two strips saved from step number eight to 34 inches. Nail each 34-inch strip to the insides of the dividers so that they are parallel to, and 1 inch away from, the boards attached to the front. This creates a 1-inch vertical slot on the inside of each divider.
11. Cut the six 8-foot lengths of 1 x 6 lumber into eighteen slats, each 31 1/4 inches long. Insert the horizontal slats, six per bin, between the dividers and into the vertical slots.
12. (Optional) Cut the 4-x-8-foot sheet of exterior plywood into two 3-x-3-foot pieces. Cut the 4-x-4-foot sheet of exterior plywood into one 3-x-3-foot piece on one of the three bins, and attach each to the back, top board with two hinges.
13. (Optional) For complete rodent protection, cut sheet metal to fit bottoms of bins.
14. Stain all untreated wood.



CONCRETE-BLOCK THREE-BIN TURNING UNIT

A concrete-block turning unit looks like three concrete-block holding units in a row. It is sturdy and, if used concrete blocks are available, it is inexpensive to build. The concrete-block unit cannot be conveniently pest-proofed.





Materials and Tools

- eighty-six concrete blocks
- four concrete half-blocks
- work gloves
- wooden or metal posts to stabilize the bin.

Building a concrete-block turning unit

1. Place twenty-five concrete blocks along the ground at the composting site as shown in the illustration below. Leave about 1/2 inch between each block to let in air.



The illustration above shows a concrete block with a central slit that makes it easy to split into two half blocks. Score each side of the block in the plane of the slit with a chisel. Then use the chisel and a hammer to split the block along the score.

2. Add a second layer of blocks, staggering them to increase stability. Using the turning unit illustration above as a guide, place ten full and two half-blocks along the back wall, and three blocks along each side. Leave about 1/2 inch between each block.
3. Add a third layer of blocks, again staggering them to increase stability. Place twelve blocks across the back of the enclosure and three blocks on each side.
4. The last, and top, layer should have ten full and two half-blocks across the back and two full blocks along each side.
5. To make the unit more stable, drive wooden or metal posts through the holes in the blocks.

WOODEN THREE-BIN TURNING UNIT

This turning unit is a permanent, sturdy structure, but it may be difficult to space the posts to the exact dimensions illustrated. Before cutting the removable slats that slide into the grooves at the front of each bin, cut one slat and check for proper fit in each bin.


Materials

(All lumber should be pressure-treated)


- eight 4-inch x 4-inch x 6-foot posts
 - seven 1-inch x 6-inch x 12-foot back slats
 - fourteen 1-inch x 6-inch x 4-foot end/side slats
 - four 1-inch x 6-inch x 4-foot fronts
 - fourteen 1-inch x 6-inch x 46 1/4-inch dividers
 - twenty-four 1-inch x 6-inch x 42 13/16-inch (approximate) front slats
- [Note: before cutting all the front slats, cut one and check for proper fit in each bin.]
- four 1-inch x 1(+)-inch x 4-foot cleats, rip cut from one four-foot 1 x 6 (the cleats are retainers for slats)
 - 8d galvanized deck nails or deck screws
 - one tube exterior construction adhesive
 - (optional) one 1-inch x 6-inch x 12-foot top rail

Tools

- post hole digger
- hammer
- saw
- tape measure
- drill




1. On level ground, set the eight posts as shown below using a post hole digger. (The posts are shown as darkened squares.) Embed each post 2 feet into the ground. Be sure all posts are plumb (perpendicular to the ground). The top of each post should be at the same distance above the ground (48 inches).



[Note: Dimensions given for the back are included to assist in post spacing.]


2. Nail (or screw) on the back and side slats and dividers (pre-drill all holes to prevent splitting). Use adhesive on all joints. The bottom slats should be at ground level. Leave 1 1/2-inch (horizontal) spaces between slats. Note that the ends of the dividers should come out to 1 inch behind the front of the front posts, as shown in the illustration above.
3. Install the fronts and cleats, as shown for one of the center divider posts at right.
4. After the front slats have been sized and cut, slide them into place between the fronts and cleats as shown in the completed bin illustration above.



5. (Optional) Nail the top rail to each front post, as shown in the completed bin illustration above. Do not use adhesive, and do not drive the nails in fully, as they will be removed to allow access to the slats. The top rail is suggested to prevent the front posts from moving laterally. Another option to discourage this is to use 4-inch x 4-inch x 7-foot posts and embed them one foot deeper.

GARBAGE-CAN COMPOSTER

A garbage-can composter is inexpensive and easy to build. It can be used for food or garden wastes. The wastes do, however, need to be turned.



Materials

- garbage can with cover
- coarse sawdust, straw, or wood chips

Tools

- drill
- pitch fork, shovel, or compost turner
- work gloves

Building a Garbage-Can Composter

1. Drill three rows of holes 4 to 6 inches apart all around the sides of the garbage can. Then drill several holes in the base of the garbage can. The holes allow air movement and the drainage of excess moisture.
2. Place 2 to 3 inches of dry sawdust, straw, or wood chips in the bottom of the can to absorb excess moisture and let the compost drain.